Low Voltage Monitoring $V_{ m in}$ $1 \,\mathrm{k}\Omega \pm 1 \,\%$ \overline{R}_{21} $10 \,\mathrm{k}\Omega \pm 1 \,\%$ R_{22} $1 \text{ k}\Omega \pm 1 \%$ **High Voltage Monitoring**

